






Nurajack Safety Grid Installation Guide for Adhered Tiles & Pavers

1. Sweep substrate clear of debris.	
2. Install Nurajacks and Safety Grid as per Installation Video found HERE . Install additional Nurajacks in the centre of each Safety Grid.	
3. Ensure Safety Grid is flat, firm and stable. Check surface with 1.8m straight edge.	
4. Install additional Nurajacks as required.	
5. Ensure Safety Grid layout enables outlets to be accessible for cleaning.	
6. Rag wipe or roller Soudal 696 solvent over the entire Safety Grid surface using a 20mm nap roller and allow to dry.	
7. Chalk line or laser tile/paver layout on Safety Grid. Ensure full tiles are over the outlets.	
8. Apply 8mm bead of Soudal 940FC PU adhesive to area for each tile, ensuring the perimeter, diagonals and centre of the tiles have appropriate adhesion. Approximately 2 x 600ml sausage of adhesive is required for every 1m2. Black colour available.	
9. Install Nurajack 3mm Shims in areas that do not have adhesive to ensure adhesive is compressed to 3mm.	
10. Install tile and press firm.	
11. To space tiles/pavers, install compressible tile spacers in the corners as required.	
12. Allow to cure for 7 working days at 22 degrees Celsius.	
13. For outlets and other areas that need access, loose lay the tile/paver over the Safety Grid with additional 3mm Shims for support.	

NOTE: Testing of the tiles/pavers for suitability of installation is highly recommended.